

A CFD Approach for Investigating DPM Concentration over Multiple Work Cycles of an LHD in an Underground Mine

Hongbin Zhang

MDEC, Toronto, ON
Oct 3 - 5, 2017



Outline

- Research Objectives
- Prior Work
- Experiment Overview
- CFD simulation of the DPM concentration distribution over three work cycles of a LHD
- Discussion

Research objectives



- Use CFD to figure out the acceptable airflow requirement to dilute the DPM level under the regulatory limit
- Investigate the DPM concentration behaviour over multiple work-cycles of a LHD in a dead-end heading

3


Prior Work

- Experiment in an underground mine in the western U.S.
- Methodology of hybrid model established
- Initial findings published in the MPES 2017 conference

4




Simple network model,
Simple 3D CFD model, and
Hybrid CFD-network model




7

Plan View of the Experiment Area




8

Geometry of the Experiment Area



9

LHD Path



10

DPM Simulation in Ansys Fluent

Boundary conditions:

	area (m2)	Velocity inlet (m/s)	DPM mass fraction	DPM (µg/m3)	Temperature (K)
Ventilation tubing	0.89	35.97	0	0	300
Main drift	34.08	1.61	0	0	300
LHD exhaust tailpipes (1 to 18)	0.093	profile (calculated)	profile (calculated)	profile (calculated)	594

$$DPM \text{ mass fraction} = \frac{DPM \text{ concentration } \left(\frac{\mu g}{m^3}\right)}{air \text{ density } \left(\frac{kg}{m^3}\right)} \times \frac{kg}{10^9 \mu g}$$


11

Assumptions

- In a work cycle, the DPM concentration from an LHD's tailpipe is the lowest when it is tramming into a heading with the bucket empty.
- The DPM concentration is the highest while the LHD is mucking in the heading.
- The DPM concentration is between the two concentrations mentioned above while the LHD is tramming out of the heading.
- It takes an LHD much longer to move out of a heading than to move into the heading.
- The DPM concentration levels are stable in each part of an LHD's work cycle.
- NOTE: The work to-date does not account for any effect of the LHD on the DPM concentration distribution in the heading in a work cycle of the LHD


12

DPM Concentration Profile from the LHD Tailpipe




13

Velocity Profile from the LHD Tailpipe




14

Partial DPM data collected by the Airtec DPM monitor at location D



15



DPM Concentration Comparison at Location C in the Experiment and the CFD Model



This work was made possible by the facilities of the Shared Hierarchical Academic Research Computing Network (SHARCNET: www.sharcnet.ca) and Compute/Calcul Canada.



16

DPM Concentration Comparison at Location D in the Experiment and the CFD Model




17

DPM Concentration Comparison at Location E in the Experiment and the CFD Model



18

Error Analysis (CFD and Experiment)



	C	D	E
R-squared	0.67	0.94	0.50

19

Main Conclusions

- The approach of using multiple tailpipes to simulate the DPM concentration generated from a work cycle of an LHD is feasible.
- The CFD model is capable of offering detailed contours of airflow and DPM concentration but it is computationally intensive
- Future work: simulate more work cycles in order to explore the DPM concentration behaviour and determine the optimum airflow quantity that keeps the DPM concentration under the regulatory limit

20

Outline

- Research Objectives
- Prior Work
- Experiment Overview
- CFD simulation of the DPM concentration distribution over three work cycles of a LHD
- Discussion


21

Outline

- Research Objectives
- Prior Work
- Experiment Overview
- CFD simulation of the DPM concentration distribution over three work cycles of a LHD
- Discussion


22

Plan View of the Experiment Area




23

Location of a Monitor Point



24

LHD Path



25


Geometry of the Experiment Area

Dimensions:

Main drift (W x H): **4.3m x 5.5m**
 Working face (W x H): **4.6m x 5.5m**
 Tubing diameter: **1.1m**

Distance from tailpipe 1 to face: **7.6m**
 Distance from end of tubing to face: **25.5m**

The tailpipes are **3m** apart from each other.



26

DPM Simulation in Ansys Fluent


Boundary conditions:

	area (m2)	Velocity inlet (m/s)	DPM mass fraction	DPM ($\mu\text{g}/\text{m}^3$)	Temperature (K)
Ventilation tubing	0.89	various values	0	0	300
Main drift	22.4	0.084	0	0	300
LHD exhaust tailpipes (1 to 12)	0.093	profile (calculated)	profile (calculated)	profile (calculated)	594

$$\text{DPM mass fraction} = \frac{\text{DPM concentration } \left(\frac{\mu\text{g}}{\text{m}^3}\right)}{\text{air density } \left(\frac{\text{kg}}{\text{m}^3}\right)} \times \frac{\text{kg}}{10^9 \mu\text{g}}$$


27

Possible DPM Profile From an LHD Tailpipe




28

DPM Concentration Profile from the LHD Tailpipe



29

Velocity Profile from the LHD Tailpipe



30

DPM Concentration Comparison at the Monitor Points

Distance from the face:


- 5 m
- 8 m
- 11 m
- 14 m

Ventilation tubing inlet velocity:

- 10.00 m/s
- 15.00 m/s
- 20.00 m/s
- 25.00 m/s
- 35.00 m/s
- 35.97 m/s

31


DPM Concentration Comparison at Monitor Point (5 m away from the face)



This work was made possible by the facilities of the Shared Hierarchical Academic Research Computing Network (SHARCNET: www.sharcnet.ca) and Compute/Calcul Canada.


32

DPM Concentration Comparison at Monitor Point (8 m away from the face)




33

DPM Concentration Comparison at Monitor Point (11 m away from the face)



34

DPM Concentration Comparison at Monitor Point (14 m away from the face)



35

DPM Concentration Comparison at the Monitor Planes

Distance from the face:


- 5 m
- 8 m
- 11 m
- 14 m

Ventilation tubing inlet velocity:

- 10.00 m/s
- 15.00 m/s
- 20.00 m/s
- 25.00 m/s
- 35.00 m/s
- 35.97 m/s


36

DPM Concentration Comparison at Monitor Plane (5 m away from the face)




37

DPM Concentration Comparison at Monitor Plane (8 m away from the face)




38

DPM Concentration Comparison at Monitor Plane (11 m away from the face)



39

DPM Concentration Comparison at Monitor Plane (14 m away from the face)




40

DPM Concentration Comparison at the Monitor Points

- Ventilation tubing inlet velocity:
- 10.00 m/s
 - 15.00 m/s
 - 20.00 m/s
 - 25.00 m/s
 - 35.00 m/s
 - 35.97 m/s
- Distance from the face:
- 5 m
 - 8 m
 - 11 m
 - 14 m
-


41

DPM Concentration Comparison at the Monitor Points (Ventilation Tubing Inlet Velocity = 10 m/s)




42

DPM Concentration Comparison at the Monitor Points (Ventilation Tubing Inlet Velocity = 15 m/s)




43

DPM Concentration Comparison at the Monitor Points (Ventilation Tubing Inlet Velocity = 20 m/s)




44

DPM Concentration Comparison at the Monitor Points (Ventilation Tubing Inlet Velocity = 25 m/s)




45

DPM Concentration Comparison at the Monitor Points (Ventilation Tubing Inlet Velocity = 30 m/s)



46

DPM Concentration Comparison at the Monitor Points (Ventilation Tubing Inlet Velocity = 35.97 m/s)



47

DPM Concentration Comparison at the Monitor Planes

Ventilation tubing inlet velocity:


- 10.00 m/s
- 15.00 m/s
- 20.00 m/s
- 25.00 m/s
- 35.00 m/s
- 35.97 m/s

Distance from the face:

- 5 m
- 8 m
- 11 m
- 14 m


48

DPM Concentration Comparison at the Monitor Planes (Ventilation Tubing Inlet Velocity = 10 m/s)




49

DPM Concentration Comparison at the Monitor Planes (Ventilation Tubing Inlet Velocity = 15 m/s)




50

DPM Concentration Comparison at the Monitor Planes (Ventilation Tubing Inlet Velocity = 20 m/s)




51

DPM Concentration Comparison at the Monitor Planes (Ventilation Tubing Inlet Velocity = 25 m/s)




52

DPM Concentration Comparison at the Monitor Planes (Ventilation Tubing Inlet Velocity = 30 m/s)



53

DPM Concentration Comparison at the Monitor Planes (Ventilation Tubing Inlet Velocity = 35.97 m/s)



54

Conclusions and Future Work

- The lower the ventilation tubing inlet velocity, the higher the DPM concentration will get.
- When the ventilation tubing velocity is greater than 10 m/s, the highest DPM concentration does not increase significantly after the second work cycle of the LHD.
- The DPM concentration does not accumulate after each work cycle of the LHD; specifically, the lowest DPM concentration near the face does not increase.
- When the ventilation tubing inlet velocity is 10 m/s, the further the monitor is from the face (within 14 m), the higher the DPM concentration will be.
- When the ventilation tubing inlet velocity greater than 15 m/s, the DPM concentration profile along the heading does not vary over the work cycles of the LHD.

Future work:

- Results will be compared with experimental data
- Mesh independence study
- Sensitivity study on the spacing between the tailpipes
- Test the effects from different locations of the ventilation tubing in the heading
- Apply the findings to the Schedule Optimization Tool (SOT)

55

Thank you



Prof. Ming Cai

Dr. Lorrie Fava

Prof. Nick Vayenas

Prof. Felipe Calizaya

Dr. Jozef Stachulak

CANMET

56